

# BROADCAST<sup>®</sup> tools INC

## *Installation and Operation Manual*



### **SR-4** *Smart Relay 4*

Firmware Version 1.01 or above (PCB Rev A & B)

Manual Update: 09/12/11

Due to the dynamic nature of product design, the information contained in this document is subject to change without notice. Broadcast Tools, Inc., assumes no responsibility for errors and/or omissions contained in this document. Revisions of this information or new editions may be issued to incorporate such changes.

*Broadcast Tools<sup>®</sup> is a registered trademark of Broadcast Tools, Inc.  
Copyright, 1989 - 2007 by Broadcast Tools, Inc. All rights reserved.  
No part of this document may be reproduced or distributed without permission.*

Visit [www.broadcasttools.com](http://www.broadcasttools.com) for important product update information.

## Table of Contents

Section Title	Page #
Introduction . . . . .	3
Safety Information . . . . .	3
Who to Contact for Help . . . . .	3
Product Description . . . . .	4
Features . . . . .	4
Applications . . . . .	4
Installation: . . . . .	5
Timing Programming . . . . .	5
HyperTerminal Set-up. . . . .	5
Logic Programming . . . . .	7
Input and Relay wiring . . . . .	9
Input jumper set-up. . . . .	10
Slave Relay Set-up . . . . .	11
Mounting. . . . .	11
RJ21X Set-up . . . . .	11
RJ21X Wiring documentation . . . . .	11
Specifications . . . . .	12
Warranty . . . . .	13
Schematic and Component Layout . . . . .	Appendix

**WEBSITE:**  
 Visit our web site for  
 product updates and  
 additional information.



## INTRODUCTION

Thank you for your purchase of a Broadcast Tools® Smart Relay 4, (referred to as the SR-4 throughout this manual). We're confident that this product will give you many years of dependable service. This manual is intended to give you all the information needed to install and operate the Broadcast Tools® Smart Relay 4.

## SAFETY INFORMATION

Only qualified personnel should install Broadcast Tools® products. Incorrect or inappropriate use and/or installation could result in a hazardous condition.

Broadcast Tools, Inc., is unable to support NON-Broadcast Tools software, hardware or NON-Broadcast Tools computer/hardware/software problems. If you experience these problems, please research your hardware/software instruction manuals or contact the manufacturers technical support department.

## WHO TO CONTACT FOR HELP

If you have any questions regarding your product or you need assistance, please contact your distributor from whom you purchased this equipment.

If you would like more information about Broadcast Tools® products, you may reach us at:

### Broadcast Tools, Inc.

131 State Street  
Sedro-Woolley, WA 98284-1540 USA  
Voice: 360.854.9559  
Fax: 866.783.1742

Internet Home Page: [www.broadcasttools.com](http://www.broadcasttools.com)  
E-mail: [support@broadcasttools.com](mailto:support@broadcasttools.com)

**THANK YOU FOR CHOOSING  
BROADCAST TOOLS® BRAND PRODUCTS!**



## CAUTION!

**Broadcast Tools®** Products, as with any electronic device, can fail without warning. Do not use this product in applications where a life threatening condition could result due to failure.



## NOTE:

This manual should be read thoroughly before installation and operation.

## WEBSITE:

Visit our web site for product updates and additional information.



## INTRODUCTION

## Product Description

The SR-4 provides four independent interfaces equipped with two optically isolated wet or dry inputs and a 2PDT relay. Additional features include; Independent user programmable logic and pulse stretching (delays) from 50ms to 99 hours, 59 minutes, 59.99 seconds. The SR-4 is supplied in a single small profile aluminum chassis. Mounting options range from surface mounting, DIN rail, two units mounted on the RM-3, 1-RU rack shelf or up to twelve units on the RA-12, 3-RU rack panel.

## Features:

- All I/O connections via screw terminals or the RJ-21X, punch block cable option.
- Each 2PDT relay section can be configured with two independent 5 to 28 vdc optically isolated wet or (5-volt) dry inputs.
- LED indicators are provided for each relay, power and programming.
- Fifteen logic functions include, sustained, toggle, set-reset (flip-flop), dual alternate action or failing/rising edge, along with additional Boolean logic functions.
- The independent pulse stretcher or time delays may be user programmed from 50ms to 99 hours, 59 minutes, 59.99 seconds.
- Independent four position dipswitches are provided for all logic function configurations.
- Non-dedicated PC (w/HyperTerminal) is used for independent timing configurations.
- Dual power jacks allows for the daisy chaining of units from one wall supply.

## Applications:

- Convert differing logic levels to 2PDT contact closures
- Time delay relays
- Pulse stretcher
- Sustained contact to pulse converters
- Rising and/or falling edge pulse converters
- Latching (flip-flop) relays
- Toggle action relays
- Dual alternate action relays
- Additional Boolean logic functions include; XOR, AND, NAND, OR, NOR.

## WEBSITE:

Visit our web site for product updates and additional information.



## Installation

Please examine your Smart Relay 4 carefully for any damage that may have been sustained during shipping. If any is noted, please notify the shipper immediately and retain the packaging for inspection by the shipper. The package should contain the Smart Relay 4, 9vac, 1 amp wall power transformer, daisy-chain cable and this manual.

### Timing Programming:

Windows HyperTerminal setup.

### ! NOTE:

*The following instructions are for use with Windows 95/98/ME/NT/2000/XT HyperTerminal.*

You can start HyperTerminal by clicking Start, pointing to Programs, pointing to Accessories, pointing to Communications, clicking HyperTerminal, and then double-clicking on the icon labeled Hypertrm or Hypertrm.exe. Follow the steps below:

1. A new window will open labeled "CONNECTION DESCRIPTION".
2. In this window, type a name that describes the connection (We suggest SR-4), click the appropriate icon, if desired and click OK.
3. A new window will open labeled "CONNECT TO".
4. At the "CONNECT TO" screen, move your cursor to the "CONNECT USING" box.
5. Press the down arrow on the right of the box to select the available com port "Direct to com x"), where "x", (usually a number from 1 through 4) is an operating com port.
6. Then click the OK button.
7. The PORT SETTING window will appear.
8. At the PORT SETTING window, Change the baud rate to 9600.
9. Change flow control to NONE.
10. Then click OK button.

You will have a new window labeled with the Connection Description you typed in earlier (in our example, SR-4).

11. At this window, click in the word CALL at the upper center portion of the menu bar and click on the word "DISCONNECT".
12. Click on the word FILE at the upper left portion of the menu bar and click on Properties.
13. Click the Settings tab, then click on EMULATION and change to ANSI,
14. Click on the ASCII setup tab, then click the box "echo typed characters locally".

15. Click the OK button.
16. Click on FILE, click Save.
17. Click on CALL, click Call.
18. HyperTerminal is now ready. Check the bottom right side of screen for a running timer.
19. Remove the SR-4 cover and attach the free end of the supplied modular cord to the RJ11 behind the power jacks.
20. Take the other end of the modular cable that has the modular to DB-9 female adapter attached and plug that in to your PC's com port.
21. Push the PGM button and the timer menu will be displayed:

### Timing Programming:

TIMER MENU, HOURS: MINUTES: SECONDS.00

CH1: 00:00:00.05  
CH2: 00:00:00.05  
CH3: 00:00:00.05  
CH4: 00:00:00.05

TO CHANGE, SELECT 1,2,3,4:

Each of the four channels can be programmed with a timer value of 0 to 99 hours, 59 minutes, 59.99 seconds. Make a selection of 1,2,3 or 4 to set the timer value for that particular section. Press the ESC key or push the PGM button to exit. Reinstall the cover.

**! NOTE:** To program default timer values, hold down the RESET button and the PGM button. Release the reset button first. The PGM LED will come on for 2 seconds to show that the default values were programmed. Default timing value is 50ms for each section.

**! NOTE:** If the reset switch isn't installed, remove power; hold down the PGM switch while powering up the SR-4, then release the PGM switch.

## Logic Programming:

**! NOTE:** Each section can be independently programmed. Sections may be combined to form custom logic/timing functions.

To program the logic functions for each section, follow the step below:

1. Remove power.
2. Remove the cover.
3. Determine which section you need to program:
4. SW 3 = K1, SW4 = K2, SW5 = K3, SW6 = K4.
5. Select the desired mode and set the dipswitches accordingly.
6. When finished, reinstall the cover and repower the SR-4.

DIP Switch Mode Settings – Dipswitches 1 through 4 are weighted 8421 (standard binary format). Example: Dipswitch 1 has a weight of 8, while Dipswitch 4 has a weight of 1.

Mode	DIPswitch	Description
0	0000	Relay closes when the odd input is active and opens when the odd input is inactive.
1	0001	Relay toggles on leading edge of the odd input.
2	0010	The relay closes on the leading edge of the odd input. Relay remains closed until the leading edge of the even input is active.
3	0011	The relay closes after the odd input has been active for the programmed time period. It opens after the even input is closed for the time period.
4	0100	The relay closed on the leading edge of the odd input. The relay opens after the trailing edge is closed for the time period.
5	0101	Relay closes on leading edge of the odd input for time period.
6	0110	Relay closes for the time period on the trailing edge of the odd input.
7	0111	Relay closes for the time period on the leading or trailing edge of the odd input.
8	1000	Relay closes on leading edge of the odd input and remains closed for at least the time period. If the odd input stays active for longer than the time period, the relay will open on the trailing edge of the odd input.
9	1001	Relay closes on the leading edge of the odd input for no longer than the time period. If a trailing edge is encountered before the time has expired, the relay will open with the edge. Otherwise, the relay opens when the time period expires.

## WEBSITE:

Visit our web site for product updates and additional information.



## INSTALLATION

Mode	DIPswitch	Description
10	1010	Two input NOR (0 = input inactive, 1 = active) 00 1 01 0 10 0 11 0
11	1011	Two input OR 00 0 01 1 10 1 11 1
12	1100	Two input XOR 00 0 01 1 10 1 11 0
13	1101	Two input AND 00 0 01 0 10 0 11 1
14	1110	Two input NAND 00 1 01 1 10 1 11 0
15	1111	Reserved (feature creep).

Installation of the Smart Relay 4 in high RF environments should be performed with care. Shielded cable is suggested for all connections. All shields should be tied to the EGND terminals. The station ground should be connected to the chassis ground screw located on the far right side of the SR-4 as viewed from the rear. It is recommended that all cables connected to the SR-4 be looped through ferrite cores to suppress RF. Surge protection with RF filtering is also suggested for the wall transformer. The purchase of an inexpensive UPS will provide back up in case of power outages.

Connections are via screw terminals and/or the RJ-21X option. Remove about 1/8" of insulation from each wire. Insert the wire into the desired terminal and tighten the screw. Be sure no bare wires are exposed.

**! NOTE:** Refer to page 11 of this manual when using the RJ-21X option.



## Inputs and Relay:

Each section has two independent inputs and one 2PDT relay. Each optically isolated input can be configured for either wet or dry operation. The factory configuration is supplied as dry. Follow the top cover label information or the text below for the desired connection and jumper settings:

The K1 section is accessed on TB1. Follow the list below for connection information. The JP(#) number in parentheses is the opto-isolator configuration header:

- 1 - Input 1A (JP1)
- 2 - Input 1B (JP1)
  
- 3 - Input 2A (JP2)
- 4 - Input 2B (JP2)
  
- 5 - Ground
- 6 - Slave K1 relay input (pull to ground to activate K1)
  
- 7 - K1A Normally Closed
- 8 - K1A Common (wiper)
- 9 - K1A Normally Open
- 10 - K1B Normally Closed
- 11 - K1B Common (wiper)
- 12 - K1B Normally Open

The K2 section is accessed on TB2. Follow the list below for connection information. The JP(#) number in parentheses is the opto-isolator configuration header:

- 1 - Input 3A (JP3)
- 2 - Input 3B (JP3)
  
- 3 - Input 4A (JP4)
- 4 - Input 4B (JP4)
  
- 5 - Ground
- 6 - Slave K2 relay input (pull to ground to activate K2)
  
- 7 - K2A Normally Closed
- 8 - K2A Common (wiper)
- 9 - K2A Normally Open
- 10 - K2B Normally Closed
- 11 - K2B Common (wiper)
- 12 - K2B Normally Open

## WEBSITE:

Visit our web site for product updates and additional information.



## INSTALLATION

The K3 section is accessed on TB3. Follow the list below for connection information. The JP(#) number in parentheses is the opto-isolator configuration header:

- 1 - Input 5A (JP5)
- 2 - Input 5B (JP5)
  
- 3 - Input 6A (JP6)
- 4 - Input 6B (JP6)
  
- 5 - Ground
- 6 - Slave K3 relay input (pull to ground to activate K3)
  
- 7 - K3A Normally Closed
- 8 - K3A Common (wiper)
- 9 - K3A Normally Open
- 10 - K3B Normally Closed
- 11 - K3B Common (wiper)
- 12 - K3B Normally Open

The K4 section is accessed on TB4. Follow the list below for connection information. The JP(#) number in parentheses is the opto-isolator configuration header:

- 1 - Input 7A (JP7)
- 2 - Input 7B (JP7)
  
- 3 - Input 8A (JP8)
- 4 - Input 8B (JP8)
  
- 5 - Ground
- 6 - Slave K4 relay input (pull to ground to activate K4)
  
- 7 - K4A Normally Closed
- 8 - K4A Common (wiper)
- 9 - K4A Normally Open
- 10 - K4B Normally Closed
- 11 - K4B Common (wiper)
- 12 - K4B Normally Open

### Input jumper set-up:

Each input is equipped with a four-position header. The header is labeled JPx and is numbered 1 through 8. The factory default is for a DRY input (switch, contact, open collector) with a jumper between 1 & 2 and another jumper over 3 & 4. To change the input to WET (user supplied voltage between 5 and 24vdc), remove both jumpers and place ONE jumper over pins 2 & 3.

**! NOTE:** Refer to the schematic diagram for the proper polarity when attaching equipment to the inputs.

## Slave Relay Connection:

The slave output can be used to drive one or all of the other sections and/or additional SR-4's. Connect a jumper wire between each of the "SL" terminals.

## Mounting:

Mount up to two units on the RM-3 or up to twelve on the RA-12.

**! NOTE:** Special brackets are required for DIN rail mounting. Please contact the factory for information and pricing.

## Power:

The supplied 9vac wall transformer may be used to power the SR-4. Up to three additional SR-4's may be powered from the same wall transformer by unitizing the supplied daisy chain cable. The user may also power the SR-4 from the punch block if this option is employed.

## RJ-21X option:

To install this option, follow the steps below:

1. Remove power from the SR-4.
2. Remove the cover.
3. Locate J4, the 50-pin shrouded keyed header.
4. Insert the 50-pin IDC KEYED connector into J4 (it only inserts one way).
5. Lay the ribbon cable over terminals TB2 and TB3.
6. Carefully install the cover, while tucking the ribbon cable under the cover lip.
7. Install the AMP champ 50-pin connector in to the user supplied RJ-21X punch block connector.
8. Follow the spreadsheet on the next page for wiring information.
9. Reapply power to the SR-4 when the installation is complete.

## WEBSITE:

Visit our web site for product updates and additional information.



## Specifications

Logic:	Flash uProcessor with non-volatile memory
Inputs:	Optically isolated (5 to 24vdc) wet or dry. Default = Dry (5 volt internally sourced)
Relays:	2PDT, 1 amp @ 30Vdc. Sealed relays utilizing  2 - form – C, Bifurcated-Crossbar silver alloy with gold overlay contacts. Equipped with LED indicators.  <b>! NOTE:</b> For safety, never connect 120 Vac circuits to these relays!
Connectors:	Screw terminals, 2.1mm power jacks and/or the RJ-21X punch block option.
Power Requirements:	9 to 24 volts AC/DC, 200 ma. 9 Vac @ 1 amp wall transformer supplied. Equipped with LED power indicator.
Physical Dimensions:	7.75" x 4" x 1.25" (WDH)
Weight:	2.0 lb.
Shipping Weight:	3.0 lb.
Options:	RM-3 Rack shelf. 1- RU.  RA-12 Rack panel. 3-RU.  RJ-21X punch block cable option (18" ribbon cable with mating connectors). <b>NOTE:</b> The Siemon S66M1-50R is NOT supplied but recommended.  USB-RS-232 smart adapter cable.  DIN rail brackets are special order only.

### WEBSITE:

Visit our web site for product updates and additional information.



## SPECIFICATIONS

## LIMITED WARRANTY

The term “Buyer” as used in this document refers to and includes both (but only) (a) any person or entity who acquires such an item for the purpose of resale to others (i.e., a dealer or distributor of an item), and (b) the first person or entity who acquires such an item for such person’s or entity’s own use.

Broadcast Tools warrants to each Buyer of any item manufactured by Broadcast Tools that the item will be free from defects in materials and workmanship at the time it is shipped by Broadcast Tools if the item is properly installed, used and maintained.

## EXCLUSIVE REMEDIES

If Broadcast Tools is notified, in writing, of a failure of any item manufactured by Broadcast Tools to conform to the foregoing Limited Warranty within one (1) year following the date of the Buyer’s acquisition of the item, and if the item is returned to Broadcast Tools in accordance with Broadcast Tools’ instructions for confirmation by inspection of the defect (which at Broadcast Tools’ election may include, without limitation, a requirement that the Buyer first obtain a Return Authorization number from Broadcast Tools, that the Buyer furnish proof of purchase in the form of an invoice and/or receipt, and that the Buyer prepay all freight charges associated with any return of the item to Broadcast Tools using such freight service as Broadcast Tools reasonably may specify), Broadcast Tools will repair or replace the defective item, or will refund the purchase price paid by the Buyer for the item. Broadcast Tools shall have the exclusive right to choose between these alternative remedies.

## NO OTHER WARRANTIES OR REMEDIES

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, BROADCAST TOOLS AND ITS SUPPLIERS DISCLAIM ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE; AND THE FOREGOING ALTERNATIVE REMEDIES SHALL BE EXCLUSIVE OF ALL OTHER REMEDIES. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS, WHICH VARY FROM STATE/JURISDICTION TO STATE/JURISDICTION.

## NO LIABILITY FOR CONSEQUENTIAL DAMAGES

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, NEITHER BROADCAST TOOLS NOR ANY OF ITS SUPPLIERS SHALL HAVE ANY LIABILITY FOR ANY SPECIAL, INCIDENTAL, INDIRECT, CONSEQUENTIAL OR PUNITIVE DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, ANY DAMAGES FOR LOST PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA OR INFORMATION, COST OF CAPITAL, CLAIMS OF CUSTOMERS, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR THE INABILITY TO USE ANY ITEM SUPPLIED BY BROADCAST TOOLS, EVEN IF BROADCAST TOOLS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES HAVE ANY LIABILITY FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES. THIS LIMITATION OF LIABILITY APPLIES WHETHER A CLAIM IS ONE ALLEGING BREACH OF A CONTRACT OR WARRANTY, NEGLIGENCE OR OTHER TORT, FOR THE VIOLATION OF ANY STATUTORY DUTY, THE FAILURE OF ANY LIMITED OR EXCLUSIVE REMEDY TO ACHIEVE ITS ESSENTIAL PURPOSE, OR ANY OTHER CLAIM OF ANY NATURE. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, THIS LIMITATION MAY NOT APPLY TO YOU.

### **Broadcast Tools, Inc.**

131 State Street  
Sedro-Woolley, WA 98284 • USA


360.854.9559 **voice** • 866.783.1742 **fax**  
support@broadcasttools.com **e-mail**  
www.broadcasttools.com **website**

**PUNCH BLOCK & SCREW TERMINAL DOCUMENTATION**


<u>Optional RJ-21X Punch Block Pin Number</u>	<u>Telco Block Pair Number</u>	<u>25-Pair Cable Telco Color Code</u>	<u>Function Description</u>	<u>Screw Terminal Number:</u>	<u>User Notes</u>
26	1	White/Blue	Input 1B	<b>TB1-2(B)</b>	
1		Blue/White	Input 1A	1(B)	
27	2	White/Orange	Input 2B	4(B)	
2		Orange/White	Input 2A	3(B)	
28	3	White/Green	K1A Common	8(T)	
3		Green/White	K1A N.O.	9(T)	
29	4	White/Brown	K1 Coil (Slave Input)	6(B)	
4		Brown/White	K1A N.C.	7(T)	
30	5	White/Slate	K1B Common	11(T)	
5		Slate/White	K1B N.O.	12(T)	
31	6	Red/Blue	Ground	5(B)	
6		Blue/Red	K1B N.C.	10(T)	
32	7	Red/Orange	Input 3B	<b>TB2-2(B)</b>	
7		Orange/Red	Input 3A	<b>1(B)</b>	
33	8	Red/Green	Input 4B	<b>4(B)</b>	
8		Green/Red	Input 4A	<b>3(B)</b>	
34	9	Red/Brown	K2A Common	8(T)	
9		Brown/Red	K2A N.O.	9(T)	
35	10	Red/Slate	K2 Coil (Slave Input)	<b>6(B)</b>	
10		Slate/Red	K2A N.C.	7(T)	
36	11	Black/Blue	K2B Common	<b>11(T)</b>	
11		Blue/Black	K2B N.O.	<b>12(T)</b>	
37	12	Black/Orange	Ground	<b>5(B)</b>	
12		Orange/Black	K2B N.C.	<b>10(T)</b>	
38	13	Black/Green	Input 5B	<b>TB3-2(B)</b>	
13		Green/Black	Input 5A	1(B)	
39	14	Black/Brown	Input 6B	4(B)	
14		Brown/Black	Input 6A	3(B)	
40	15	Black/Slate	K3A Common	8(T)	
15		Slate/Black	K3A N.O.	9(T)	
41	16	Yellow/Blue	K3 Coil (Slave Input)	6(B)	
16		Blue/Yellow	K3A N.C.	7(T)	
42	17	Yellow/Orange	K3B Common	11(T)	
17		Orange/Yellow	K3B N.O.	12(T)	
43	18	Yellow/Green	Ground	5(B)	
18		Green/Yellow	K3B N.C.	10(T)	
44	19	Yellow/Brown	Input 7B	<b>TB4-2(B)</b>	
19		Brown/Yellow	Input 7A	<b>1(B)</b>	
45	20	Yellow/Slate	Input 8B	<b>4(B)</b>	
20		Slate/Yellow	Input 8A	<b>3(B)</b>	
46	21	Violet/Blue	K4A Common	8(T)	
21		Blue/Violet	K4A N.O.	9(T)	
47	22	Violet/Orange	K4 Coil (Slave Input)	<b>6(B)</b>	
22		Orange/Violet	K4A N.C.	7(T)	
48	23	Violet/Green	K4B Common	<b>11(T)</b>	
23		Green/Violet	K4B N.O.	<b>12(T)</b>	
49	24	Violet/Brown	Ground	<b>5(B)</b>	
24		Brown/Violet	K4B N.C.	<b>10(T)</b>	
50	25	Violet/Slate	SR-4 Power Supply Positive	J1/J2	
25		Slate/Violet	SR-4 Power Supply Ground	J1/J2	

# Smart Relay 4

## Input, Relay and Jumper Layout




## Fractional Schematic





# Smart Relay 4 Installation and Operation Manual



Information is provided for informational purposes only. Broadcast Tools, Inc. and shall not be used except with the written permission of Broadcast Tools, Inc. No responsibility shall be assumed for any errors or omissions in the matter contained in this information. The property of Broadcast Tools, Inc.

BROADCAST TOOLS, INC.	
Title	SMART RELAY 4
Size	Document Number: SR4B2-SCH
REV	B
Date:	JULY 13, 2006 Sheet 2 of 3