



Installation and Operation Manual



SS 2.1/Terminal III Switcher/Router

Firmware Version 3.4

Manual Revised 07/06/11

Due to the dynamic nature of product design, the information contained in this document is subject to change without notice. Broadcast Tools, Inc., assumes no responsibility for errors and/or omissions contained in this document. Revisions of this information or new editions may be issued to incorporate such changes.

*Broadcast Tools® is a registered trademark of Broadcast Tools, Inc.
Copyright, 1989 - 2011 by Broadcast Tools, Inc. All rights reserved.
No part of this document may be reproduced or distributed without permission.*

Visit www.broadcasttools.com for important product update information.

Table of Contents

Section Title	Page #
Introduction	3
Safety Information	3
Who to Contact for Help	3
Product Description	4
Features	4
Applications	4
Front Panel Description	5
Rear Panel Description	5
Installation Guidelines	5
Dip switch setup	5
Inspection	7
Removal of the source termination resistors	7
Bench test	7
Mounting	7
Connect your equipment to the unit	7
Serial operation	8
Remote control wiring	8
Jumper setup	9
Sage/Endec Configuration	10
Specifications	11
Warranty	12
EAS Applications	Appendix

INTRODUCTION

Thank you for your purchase of a Broadcast Tools® SS 2.1/Terminal III Stereo Audio Switcher/Router (referred to as the SS 2.1/Term III throughout this manual). We're confident that this product will give you many years of dependable service. This manual is intended to give you all the information needed to install and operate the Broadcast Tools® SS 2.1/Term III.

SAFETY INFORMATION

Only qualified personnel should install Broadcast Tools® products. Incorrect or inappropriate use and/or installation could result in a hazardous condition.

WHO TO CONTACT FOR HELP

If you have any questions regarding your product or you need assistance, please contact your distributor from whom you purchased this equipment.

If you would like more information about Broadcast Tools® products, you may reach us at:

Broadcast Tools, Inc.

131 State Street
Sedro-Woolley, WA 98284 USA
Voice: 360.854.9559
Fax: 866.783.1742

Internet Home Page: www.broadcasttools.com
E-mail: support@broadcasttools.com

**THANK YOU FOR CHOOSING
BROADCAST TOOLS® BRAND PRODUCTS!**

Broadcast Tools is a Veteran Owned Business



Designed, Assembled and Supported in WA State, USA



CAUTION!

Broadcast Tools® Products, as with any electronic device, can fail without warning. Do not use this product in applications where a life threatening condition could result due to failure.




NOTE:

This manual should be read thoroughly before installation and operation.

WEBSITE:

Visit our web site for product updates and additional information



INTRODUCTION

PRODUCT DESCRIPTION

The SS 2.1/Term III passively switches or routes a variety of electrical signals to a destination. The SS 2.1/Term III selects any one of 2 stereo inputs to a single stereo output. The SS 2.1/Term III provides PASSIVE switching through gold contact relays. The passive switching means that the unit can route a signal in either direction (any one of 2 stereo inputs to a single destination, or a single source to any one of 2 destinations). Due to the passive nature of the switching, any input level and impedance can be used. Inputs may be balanced or unbalanced, while output levels, impedance, distortion, noise and balancing will match that of the selected input. In addition to their normal use with audio signals, the unit can also be used to switch digital signals and telephone lines.

FEATURES

- Operation by front panel switches and LED indicators, contact closures, 5-volt TTL/CMOS logic levels and/or the multi-drop RS-232 serial port.
- Removable screw terminals (Euro) are provided for audio and remote control connections.
- Audio switching via sealed relays utilizing 2-form-C bifurcated-crossbar silver alloy with gold overlay contacts.
- Microprocessor control with non-volatile memory.
- The Power-Up feature allows the user to select which one source is active at power up, including the last source selected.
- Three logic-switching modes.
- The ENABLE switch provides a safety lock to the front panel selection switches.
- The audio MUTE switch allows the user to turn off the audio output when activated.
- Source number one is configured by default to route audio to the output in the case of loss of power to the unit.
- Non-selected sources are terminated with 10K Ω , load resistors.
- Relays provided for remote status.
- Desktop, wall mount or rack mount three units on the RA-1, 1-RU rack shelf.

APPLICATIONS

EAS audio switching, any type of stereo, monaural, composite audio, AES/EBU, ISDN, RS-232/422/485, telephone lines switching, multiple station program on-hold and/or PA switching.

FRONT PANEL DESCRIPTION

Source and Mute Switches:

Each switch represents an input to be routed to the switcher's output. The switches are highly reliable switches, which will give the user years of dependable service. Each switch has an associated LED indicator, which will illuminate when that particular source is routed to the output. When a source is selected, the previous source will be deselected, (interlock). The enable switch (when enabled) requires the user to hold this switch closed while selecting any of the other front panel switches. The front panel power LED illuminates when power is applied to the unit.

REAR PANEL DESCRIPTION

Power:

Connect the 2.1mm barrel type power connector into the unit and the 9 vac, 500-ma wall transformer into a 120 Vac 50-60 Hz power source. (CE, 220 Vac 50-60 Hz wall transformer OPTIONAL)

Audio and Remote Connectors:

The rear panel contains all the inputs, outputs and remote control interfacing connectors. All audio I/O and remote control connections are through pluggable screw terminals with mating connectors. The multi-drop serial port is equipped with a modular RJ-11 jack.

INSTALLATION GUIDELINES

Dip Switch setup:

Follow the tables below for options:


Unit ID	SW5-1	SW5-2
ID 0 *	OFF	OFF
ID 1	ON	OFF
ID 2	OFF	ON
ID 3	ON	ON

Baud Rate	SW5-3	SW5-4
2400	ON	OFF
9600 *	OFF	OFF
19200	OFF	ON
38400	ON	ON

Power Up	SW5-5
User selected	ON
Last source selected *	OFF

WEBSITE:

Visit our web site for product updates and additional information



DESCRIPTION

Note: To select an input at power-up with SW5-5 ON, hold down the push-button for the desired input channel or mute until the front panel LED's flash.

Operation	SW5-6	SW5-7
Normal *	OFF	OFF
Sustained	ON	OFF
EAS switcher	OFF	ON
(SAGE/ENDEC, MSRP Clone, Serial operation)		
Toggle	ON	ON

- Normal operation: Pulse 1-IN to select input 1, Pulse IN-2 to select input 2 or pulse the "M-IN" (mute) pin to turn off both channels.
- Sustained operation: Hold IN-2 low to select input 2.
- Toggle operation: Alternately pulse 1-IN to select between the two input channels.

Note: After changing any dipswitch, please repower the unit.

*** Denotes factory setting.**

It is recommended that all cables connected to the SS 2.1/Term III be looped through ferrite cores to suppress RF. Surge protection with RF filtering such as the Tripp Lite "ISOBAR 4" is also suggested for the power transformer. The purchase of an inexpensive uninterruptible power supply (UPS) will provide back up in case of power outages.

Installation of the SS 2.1/Term III consists of six steps:

1. Inspection.
2. Removal of the source termination resistors, if applicable.
3. Bench test.
4. Mount the unit on a desktop, wall or rack shelf (RA-1).
5. Connect your equipment to the unit.
6. Serial operation, if applicable.



CAUTION!

Installation of the SS 2.1 Term III in high RF environments should be performed with care. Shielded cable is suggested for all control, audio inputs and outputs. All shields should be tied to the "CHASSIS GROUND" terminal. The station ground should be connected to the chassis ground screw (CH1) located behind J5 as viewed from the rear. For lightning protection devices, check out www.polyphaser.com and www.itwlinx.com.

STEP 1: INSPECTION

Please examine your SS 2.1/Term III carefully for any damage that may have been sustained during shipping. If any is noted, please notify the shipper immediately and retain the packaging for inspection by the shipper. The package should contain the SS 2.1/Term III, 9 vac@500-ma wall power transformer, manual, reversed modular cable and “S9” 9-pin female D-Sub adapter.

STEP 2: SOURCE TERMINATION RESISTOR REMOVAL

Input sources that are not selected are terminated with a 10K Ω load (1/4 watt maximum). If you do not want this load applied across the deselected sources, it may be removed from each channel. Each channel has a pair of resistors.

EXAMPLE: Channel 1, relays K1 A&B switches the signal; R1 & R2 are the 10K Ω load resistors. As delivered, all channels are configured with these resistors installed. To remove the load resistors from a channel, locate via the schematic the proper resistors for that channel, cut its leads and discard the resistors.

STEP 3: BENCH TEST

Place each unit on a workspace and connect power to the unit. Check to see if the power LED is lit. Connect an audio source to stereo input one and a monitoring device to the output. Select channel one and verify that audio is present. Repeat the process until each channel's operation has been verified. This would also be a good time to set up the desired switch or jumper options.

STEP 4: MOUNTING

Mount the unit on a rack shelf, such as the Broadcast Tools RA-1, allowing adequate airflow for cooling. The RA-1 is furnished with filler panels to cover open spaces.

STEP 5: CONNECT YOUR EQUIPMENT

The SS 2.1/Term III interfaces to your equipment (sources, loads and remote control) through removable screw terminals. Follow the silk-screened legends for the desired connections on the rear panel of the chassis. Remove the connector and use a small screwdriver to loosen each screw terminal, insert the stripped wire (18 to 26 gauge wire), tighten the screw and reinsert the connector. Refer to the remote control connector-wiring chart on page 8.


TB1 →TB3

Typical I/O connector

I/O – Left	I/O + Left	Gnd	I/O – Right	I/O + Right
------------	------------	-----	-------------	-------------

WEBSITE:

Visit our web site for product updates and additional information



STEP 6: SERIAL OPERATION

Connecting the RS-232 serial port of the SS 2.1/Term III is accomplished by using the supplied reversed modular cable and 9-pin “S9” female D-sub adapter between the SS 2.1/Term III and controlling PC. Select the desired address for each unit. Never duplicate addresses. The default protocol is as follows: 9600, N, 8, 1 (other baud rates are user selectable).

To select a channel, send the following string: *ui

Where the

- < * > Denotes start of string character.
- < u > Unit ID (address, 0 through 3).
- < i > Input channel (1, 2 or M (MUTE)).

Example: *02 This string would turn on channel 2.
 *0M This string would MUTE the switcher’s output.
 No serial status is provided.

Apply power to the SS 2.1/Term III via the wall transformer.

The SS 2.1/Term III is now ready to be operated.

Remote Control Wiring:

Control:

The front panel switches are brought out through the rear panel remote control connector, providing a means of controlling the SS 2.1/Term III from a remote point. These digital inputs may be a momentary or sustained action, compatible with 5 volts CMOS/TTL logic, open collector or contact closures to ground. The inputs are pulled high. For wiring information, refer to the grid below.

Relays:

Relay contacts are supplied through the remote control connector as both individual dry and wet relay contacts. K3, the SPDT relay is associated with input channel one. K4 is associated with input channel two and provides SPDT dry contacts and selectable (JP3) N.O. or N.C. contacts common to the (+) positive 12vdc(400 ma, MAX) power supply. This provides a simple way to control external devices such as RF or power relays. K5 is associated with the mute function and is selectable (JP4) between the N.O. or N.C. contacts common to ground. For wiring information, refer to the grid below and/or the schematic in the rear of this manual.

TB 4		Relay Outputs		Top Row	
K3 N.O.	K3 Common	K3 N.C.	K4 N.O.	K4 Common	K4 N.C.
1-IN	2-IN	M-IN (Mute)	GND	GXK5	+XK4
Inputs & Relay Outputs				Bottom Row	

Jumpers:

JP2: Installed = Front panel enable switch defeated
Removed = Front panel ENABLE switch active. This switch must be held closed to operate any of the other front panel switches.
NOTE: This switch is NOT associated with any of the remote control functions.


JP3: NO = Brings the N.O. contact for K4 out to the remote control terminal.
NC = Brings the N.C. contact for K4 out to the remote control terminal.
Note: This terminal is labeled +XK4

JP4: NO = Brings the N.O. contact for K5 out to the remote control terminal.
NC = Brings the N.C. contact for K5 out to the remote control terminal.

Note: This terminal is labeled GXK5

WEBSITE:


Visit our web site for product updates and additional information



* SAGE ENDEC INSTALLATION GUIDELINES

The pin out of the adapter is shown below.

RJ-11 Adapter Pin	DB-9 D-Sub	SS 2.1 Term III (Point of view)
4	3	RS-232 Receive
3	2	RS-232 Transmit
2	5	Ground



Dip Switch Setup: Follow the tables below for setup options:

Unit ID: **SW5-1** **SW5-2**

ID 0 *	OFF	OFF
ID 1	ON	OFF
ID 2	OFF	ON
ID 3	ON	ON

Station ID: **SW5-3** **SW5-4**

2	ON	OFF
1 *	OFF	OFF
3	OFF	ON
4	ON	ON

Operation: **SW5-6** **SW5-7**

Normal *	OFF	OFF
Sustained	ON	OFF
EAS switcher	OFF	ON (SAGE/ENDEC, MSRP Clone, 1200 baud serial)
Toggle	ON	ON


Note: After changing any dipswitch, please repower the unit. * Denotes factory setting.

Connecting a single SS 2.1 III/Term to the Sage "Endec" serial port:

Attach the supplied "S9" DB-9 female adapter to the Sage serial port. Connect the module cable to the adapter and the other end to the RJ11 on the SS 2.1 III/Term. Configure the above dip switch SW5 for the desired operation.


Connecting two or more SS 2.1 III/Term's to the SAGE "Endec" Serial Port:

Multiple SS 2.1 III/Term may be cascaded serially to operate from the same serial port. The first step is to assign ID's to each SS 2.1 III/Term. One suggestion is to assign ID1 to the first SS 2.1 III/Term and ID2 to the second switcher. The second step is to assign a station ID to each switcher. The third step is to parallel the serial ports of the SS 2.1 III/Term's. Plug the male end of the duplex modular adapter into the supplied female "S9", DB-9 to RJ-11 adapter, then attach the supplied reversed modular line cords into each of the duplex modular adapter receptacles (Radio Shack Cat No. 279-0357) and the other ends into each of the SS 2.1 III/Term modular receptacles. See the diagram below. NOTE: Three or more SS 2.1 III/Term's may be daisy chained by using the above description and a Radio Shack Cat No. 279-0410, 5-jack modular adapter.



WEBSITE:

Visit our web site for product updates and additional information



INSTALLATION

SPECIFICATIONS

Inputs/Outputs:	Any input level and impedance can be used. Inputs may be balanced or unbalanced. Output levels, impedance, distortion, noise and balancing will match that of the selected input.
Switching Method:	Passive. Sealed relays utilizing 2-form-C bifurcated-crossbar silver alloy with gold overlay contacts.
Logic:	Flash microprocessor with non-volatile memory.
Operation Control:	Front Panel – Momentary switches. Remote – Momentary or sustained, compatible with 5 volts CMOS/TTL logic, open collector or contact closures to ground. Serial – Multi-drop RS-232, Receive only, 1200 or 2400, 9600, 19200, 38400 8, N, 1.
Status:	Front Panel – LED Indicators. Remote – SPDT & SPST relays. 1-amp 30 vdc. Refer to schematic for connection details.
Interfacing:	Audio & remote control – Rear panel pluggable screw terminals. Mating connectors supplied. RS-232 – (RJ-11) Reversed modular cable/female “S9” 9-pin D-Sub adapter supplied.
Power Requirements:	9 Vac, 500 ma. 120 Vac 50-60 Hz transformer. Supplied. (CE 240 Vac 50-60 Hz optional)
Physical Dimensions:	5.65” x 6.50” x 1.55” (WDH)
Weight:	2.0 lb.
Shipping Weight:	3.0 lb.
Options:	RA-1 rack shelf, holds three units (1-RU) / Filler panels supplied.

LIMITED WARRANTY

The term "Buyer" as used in this document refers to and includes both (but only) (a) any person or entity who acquires such an item for the purpose of resale to others (i.e., a dealer or distributor of an item), and (b) the first person or entity who acquires such an item for such person's or entity's own use.

Broadcast Tools warrants to each Buyer of any item manufactured by Broadcast Tools that the item will be free from defects in materials and workmanship at the time it is shipped by Broadcast Tools if the item is properly installed, used and maintained.

EXCLUSIVE REMEDIES

If Broadcast Tools is notified, in writing, of a failure of any item manufactured by Broadcast Tools to conform to the foregoing Limited Warranty within one (1) year following the date of the Buyer's acquisition of the item, and if the item is returned to Broadcast Tools in accordance with Broadcast Tools' instructions for confirmation by inspection of the defect (which at Broadcast Tools' election may include, without limitation, a requirement that the Buyer first obtain a Return Authorization number from Broadcast Tools, that the Buyer furnish proof of purchase in the form of an invoice and/or receipt, and that the Buyer prepay all freight charges associated with any return of the item to Broadcast Tools using such freight service as Broadcast Tools reasonably may specify), Broadcast Tools will repair or replace the defective item, or will refund the purchase price paid by the Buyer for the item. Broadcast Tools shall have the exclusive right to choose between these alternative remedies.

NO OTHER WARRANTIES OR REMEDIES

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, BROADCAST TOOLS AND ITS SUPPLIERS DISCLAIM ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE; AND THE FOREGOING ALTERNATIVE REMEDIES SHALL BE EXCLUSIVE OF ALL OTHER REMEDIES. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS, WHICH VARY FROM STATE/JURISDICTION TO STATE/JURISDICTION.

NO LIABILITY FOR CONSEQUENTIAL DAMAGES

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, NEITHER BROADCAST TOOLS NOR ANY OF ITS SUPPLIERS SHALL HAVE ANY LIABILITY FOR ANY SPECIAL, INCIDENTAL, INDIRECT, CONSEQUENTIAL OR PUNITIVE DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, ANY DAMAGES FOR LOST PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA OR INFORMATION, COST OF CAPITAL, CLAIMS OF CUSTOMERS, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR THE INABILITY TO USE ANY ITEM SUPPLIED BY BROADCAST TOOLS, EVEN IF BROADCAST TOOLS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES HAVE ANY LIABILITY FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES. THIS LIMITATION OF LIABILITY APPLIES WHETHER A CLAIM IS ONE ALLEGING BREACH OF A CONTRACT OR WARRANTY, NEGLIGENCE OR OTHER TORT, FOR THE VIOLATION OF ANY STATUTORY DUTY, THE FAILURE OF ANY LIMITED OR EXCLUSIVE REMEDY TO ACHIEVE ITS ESSENTIAL PURPOSE, OR ANY OTHER CLAIM OF ANY NATURE. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, THIS LIMITATION MAY NOT APPLY TO YOU.

Broadcast Tools, Inc.

131 State Street

Sedro-Woolley, WA 98284 • USA


360.854.9559 **voice** • 866.783.1742 **fax**

support@broadcasttools.com **e-mail**

www.broadcasttools.com **website**

Broadcast Tools® SS2.1 III/Term AES Audio, EAS with RS-232 Serial Control

Installation Application




* EAS units with an analog only output. The ADC-1 may be inserted between the analog EAS output and the AES Input 2.



Broadcast Tools® SS2.1 III/Term

Analog Audio, EAS with RS-232 Serial Control


Installation Application



Broadcast Tools® SS2.1 III/Term

AES Audio, EAS with Contact Closure Control

Installation Application



* EAS units with an analog only output. The ADC-1 may be inserted between the analog EAS output and the AES Input 2.



131 State Street, Sedro-Woolley, WA 98284 • 360.854.9559 • Fax 360.854.9479

Visit us online at www.broadcasttools.com
 Copyright © 1989-2011 by Broadcast Tools, Inc. All Rights Reserved.

Broadcast Tools® SS2.1 III/Term

Analog Audio, EAS with Contact Closure Control

Installation Application

