

BROADCAST[®] tools INC

PROBLEM SOLVED

Installation and Operation Manual



2x6 DA Plus **2X3 or 1x6 Distribution Amplifier**

Manual update: 6/16/2015

If you need a firmware upgrade, contact Broadcast Tools[®]

No part of this document may be reproduced or distributed without permission.
ALL SPECIFICATIONS AND FEATURES FOR THIS PRODUCT ARE SUBJECT TO
CHANGE WITHOUT NOTICE

NOTE: We recommend the use of Chrome, Firefox or Safari as your browser.

Due to the dynamic nature of product design, the information contained in this document is subject to change without notice. Broadcast Tools, Inc., assumes no responsibility for errors and/or omissions contained in this document. Revisions of this information or new editions may be issued to incorporate such changes.

*Broadcast Tools[®] is a registered trademark of Broadcast Tools, Inc.
All Sentinel[®] labeled products are registered trademarks of Broadcast Tools, Inc.
Copyright[®] 1989 - 2015 by Broadcast Tools, Inc. All rights reserved.
No part of this document may be reproduced or distributed without permission.*


Visit www.broadcasttools.com for important product update information.

Table of Contents

Section Title	Page #
Introduction	3
Safety Information	3
Who to Contact for Help	3
Product Overview	4
Features/Benefits	4
Inspection	4
Installation/Operation.	5
Power	5
Surge Protection.	5
UPS standby power system	5
LED indicators.	6
Input connection	6
Input Level switch	6
Audio Output connections	6
Stereo/Monaural Jumper Settings	6
Output Level adjustment	6
Specifications	7
Warranty	8
Front and rear panel drawings	Appendix
Connector and configuration jumper layout	Appendix
Fractional schematic	Appendix

WEBSITE:

Visit our web site for product updates and additional information.



CONTENTS

INTRODUCTION

Thank you for your purchase of the 2x6 DA Plus Stereo Distribution Amplifier, which we will refer to throughout the manual as the 2x6 DA Plus. We're confident this product will give you many years of dependable service. This manual is intended to give you all the information needed to install and operate the BROADCAST TOOLS® 2x6 DA Plus

SAFETY INFORMATION

Only qualified technical personnel should install the 2X6 DA PLUS. Any attempt to install this device by a person who is not technically qualified could result in a hazardous condition to the installer or other personnel or damage to the 2X6 DA PLUS or other equipment. Please ensure that proper safety precautions have been taken before installing this device. If you are unfamiliar with this type of equipment, please contact a properly qualified engineer to handle the installation and setup of the 2X6 DA PLUS. Broadcast Tools, Inc., is unable to support NON-Broadcast Tools software, hardware or NON-Broadcast Tools computer/hardware/software problems. If you experience these problems, please research your hardware/software instruction manuals or contact the manufacturers technical support department.

WHO TO CONTACT FOR HELP

If you have any questions regarding your product or you need assistance, please contact your distributor from whom you purchased this equipment. If you would like more information about BROADCAST TOOLS® products, you may reach us at:

Broadcast Tools, Inc.

131 State Street
Sedro-Woolley, WA 98284-1503 USA
Voice: 360.854.9559
Fax: 866.783.1742

Internet Home Page: www.broadcasttools.com
E-mail: support@broadcasttools.com

**THANK YOU FOR CHOOSING
BROADCAST TOOLS® BRAND PRODUCTS!**

Broadcast Tools is a Veteran Owned Business



Designed, Assembled and Supported in WA State, USA



CAUTION!

Broadcast Tools® Products, as with any electronic device, can fail without warning. Do not use this product in applications where a life threatening condition could result due to failure.




NOTE:

This manual should be read thoroughly before installation and operation.

WEBSITE:

Visit our web site for product updates and additional information.



INTRODUCTION

Product Overview

The 2x6 DA Plus stereo distribution amplifier is equipped with a stereo line level high-Z input, which accepts a balanced or unbalanced source with six active balanced low-Z output amplifiers. Each output amplifier may be paired for stereo operation or each output pair may be summed for monaural operation without affecting the stereo separation of the other outputs. Each output amplifier has a recessed front panel level control trimmer.

Features/Benefits


- Stereo or monaural output set via jumpers.
- Front panel output level trimmers.
- Switch selectable input gain for -10dBV or +4dBu sources, eliminating the need for external level conversion.
- Removable euro-block screw terminal connectors are used for audio connections. Necessary mating plugs are supplied.
- Fully RFI proofed.
- Surge protected internal power supply, PS-1515 universal switching +/- 15VDC power supply with domestic connectors supplied. International AC connectors optional.
- Up to three units may be mounted on the optional RA-1 rack shelf. Desktop and wall mounting is also possible.

Inspection

Please examine your 2X6 DA PLUS carefully for any damage that may have been sustained during shipping. If any damage is present, please notify the shipper immediately and retain the packaging for inspection by the shipper. The package should contain the 2X6 DA PLUS, and a +/-15 VDC wall power supply with domestic connector. Manuals may be downloaded from our web site.

WEBSITE:

Visit our web site for product updates and additional information.



Installation/Operation

Power

Connect the supplied PS-1515 power supply's 3-pin AMP-style latching power connector to the unit and the +/-15 VDC switching power supply with domestic connector into a 120 Vac 50-60 Hz power source. The Power+ and Power- LEDs will light to indicate proper supply voltage.

NOTE: Never use any type of power supply other than the specified/supplied power supply.

Surge Protection

The 2X6 DA PLUS has built-in resistance to voltage changes; we recommend that you use a power surge protector or line conditioner on the incoming AC line. Lightning strikes and/or other high voltage surges may damage your 2X6 DA PLUS and connected equipment if it is not properly protected. For lightning protection devices, check out www.polyphaser.com and www.itwlinx.com.

UPS Standby Power System

We recommend that you connect your 2X6 DA PLUS to a UPS system. A UPS helps minimize the risk to the 2X6 DA PLUS and provides power during a power outage.

LED indicators

- “Power+” and “Power-“ LEDs: Indicate positive and negative power supply.
- “LT Act” and “RT Act” LEDs: Indicate left and right audio input activity.

Input Connection

Connect your audio source to the DA's 5-position input terminal block. The input is labeled: “INPUT” “L-“ “L+” for the left channel and “R-“ “R+” for the right channel. Connect the cable shields to G (ground) connection. For unbalanced inputs, install a jumper between the “-” input and G (ground). Single (mono) inputs may be fed to all output channels by connecting the left and right inputs in parallel.


NOTE: Please verify proper phasing.

Input Level Switch

The input on the 2x6 DA Plus can be switched between two gain ranges using the rear panel “Input Level” switch. With the switch in the +4 dBu “in” position the input gain is set to accept a +4 dBu nominal signal. With the switch in the -10 dBu “out” position 12 db of gain is added to the input to accommodate consumer/low line level input signals.

WEBSITE:

Visit our web site for product updates and additional information.



Audio Output Connections

The 2x6 DA Plus provides balanced analog stereo outputs on three pluggable 5-position euro-block style connectors. The output level is adjustable via front panel 1-turn trimmers labeled 1-6. Connect each load to the 2 x 6 DA outputs, labeled "OUTPUTS 1L-/1L+, 2L-/2L+ and 3L-/3L+".

For unbalanced loads, use the "+" and GND terminals only. Do not connect the "-" terminal to ground. Shields should be tied to the "GND" terminals.

Output 1 (Top row, TB1)				
1L-	1L+	Gnd	1R-	1R+
L-	L+	Gnd	R-	R+
Input (Bottom row, TB1)				

Output 2 (Top row, TB2)				
2L-	2L+	Gnd	2R-	2R+
2L-	3L+	Gnd	3R-	3R+
Output 3 (Bottom row, TB2)				

Stereo/Monaural Jumper Settings


Each stereo output can be set to output a monaural sum of the left and right input audio. Follow the silk-screened "Mono" labels on the PCB. If the jumper is installed, that output will be combined to monaural. Placing a jumper over JP1 converts output one to mono, JP2 output two and JP3 addresses output three. The factory setting is Stereo. The three stereo outputs operate independently; setting one output pair to MONO has no effect on the other pairs, and does not degrade the integrity of the other stereo outputs.

Output Level Adjustment

Use the front panel left (LT) and right (RT) level adjustment trimmers to set each output channel to the desired output level.

WEBSITE:

Visit our web site for product updates and additional information.




SPECIFICATIONS

Input Level:	-10dBv or +4dBu nominal. Switch selectable. +24dBu max, @ 600
Input Impedance:	20K balanced, 10 K unbalanced
Output Level:	+4dBu nominal, + 24dBu max, @ 600 , balanced
Output Impedance:	100 balanced, 47 unbalanced
System Gain:	20 dB
Frequency Response:	+/- 0.2dB (20Hz – 20kHz)
Noise:	75 dB below nominal
Power:	PS-1515 universal switching power supply with domestic AC connector supplied. International AC connectors optional. +/-15 VDC 400mA output with 3-pin AMP-style latching power connector.
Dimensions:	6 x 5.25 x 1.63 in (W x L x H)
Options:	RA-1 Rack Shelf. 1 RU. Accommodates up to 3 units. PS-1515-500/IEC, AC line cord not supplied.

WEBSITE:

Visit our web site for product updates and additional information.



LIMITED WARRANTY

The term “Buyer” as used in this document refers to and includes both (but only) (a) any person or entity who acquires such an item for the purpose of resale to others (i.e., a dealer or distributor of an item), and (b) the first person or entity who acquires such an item for such person’s or entity’s own use.

Broadcast Tools warrants to each Buyer of any item manufactured by Broadcast Tools that the item will be free from defects in materials and workmanship at the time it is shipped by Broadcast Tools if the item is properly installed, used and maintained.

EXCLUSIVE REMEDIES

If Broadcast Tools is notified, in writing, of a failure of any item manufactured by Broadcast Tools to conform to the foregoing Limited Warranty within one (1) year following the date of the Buyer’s acquisition of the item, and if the item is returned to Broadcast Tools in accordance with Broadcast Tools’ instructions for confirmation by inspection of the defect (which at Broadcast Tools’ election may include, without limitation, a requirement that the Buyer first obtain a Return Authorization number from Broadcast Tools, that the Buyer furnish proof of purchase in the form of an invoice and/or receipt, and that the Buyer prepay all freight charges associated with any return of the item to Broadcast Tools using such freight service as Broadcast Tools reasonably may specify), Broadcast Tools will repair or replace the defective item, or will refund the purchase price paid by the Buyer for the item. Broadcast Tools shall have the exclusive right to choose between these alternative remedies.

NO OTHER WARRANTIES OR REMEDIES

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, BROADCAST TOOLS AND ITS SUPPLIERS DISCLAIM ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE; AND THE FOREGOING ALTERNATIVE REMEDIES SHALL BE EXCLUSIVE OF ALL OTHER REMEDIES. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS, WHICH VARY FROM STATE/JURISDICTION TO STATE/JURISDICTION.

NO LIABILITY FOR CONSEQUENTIAL DAMAGES

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, NEITHER BROADCAST TOOLS NOR ANY OF ITS SUPPLIERS SHALL HAVE ANY LIABILITY FOR ANY SPECIAL, INCIDENTAL, INDIRECT, CONSEQUENTIAL OR PUNITIVE DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, ANY DAMAGES FOR LOST PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA OR INFORMATION, COST OF CAPITAL, CLAIMS OF CUSTOMERS, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR THE INABILITY TO USE ANY ITEM SUPPLIED BY BROADCAST TOOLS, EVEN IF BROADCAST TOOLS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES HAVE ANY LIABILITY FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES. THIS LIMITATION OF LIABILITY APPLIES WHETHER A CLAIM IS ONE ALLEGING BREACH OF A CONTRACT OR WARRANTY, NEGLIGENCE OR OTHER TORT, FOR THE VIOLATION OF ANY STATUTORY DUTY, THE FAILURE OF ANY LIMITED OR EXCLUSIVE REMEDY TO ACHIEVE ITS ESSENTIAL PURPOSE, OR ANY OTHER CLAIM OF ANY NATURE. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, THIS LIMITATION MAY NOT APPLY TO YOU.

Broadcast Tools, Inc.


131 State Street
Sedro-Woolley, WA 98284 • USA

360.854.9559 **voice** • 866.783.1742 **fax**
support@broadcasttools.com **e-mail**
www.broadcasttools.com **website**




2X6 DA Plus

Component Layout



FRACTIONAL SCHEMATIC



FRACTIONAL SCHEMATIC

